


HOW TO USE THE SMARTBOARD in the HS/HSL distance education room



1

Turn the computer on - located behind the left side of the SmartBoard.



2

Turn the projector on – the switch is located on the lower left-hand corner of the SmartBoard screen. Press the button twice – it will turn green.



3

Turn the wireless keyboard on – the switch is located behind the “Logitech” logo.



4

Turn the wireless mouse on – the switch is on the underside of the mouse.



FOR ASSISTANCE, PLEASE DIAL RAYMOND W. HALL, 410-706-1072
OR JOHN CUNNINGHAM, 410-706-7277